



Contents Checklist


1

Please check the components after unpacking. If any of the components are missing, please contact the dealer.

Contents	Qty.
A77 Smart Mini Payment Terminal	1
AC Power Adapter	1
USB Cable	1
Battery	1
Quick Setup Guide	1

Product Description

2



SAM, SIM, & Micro SD Card

3

1. Remove the back cover.
2. Gently remove the battery from the device.
3. Insert the card into the relevant card slot.
4. Replace the battery and back cover.

Power

4

POWER ON:

Press and hold the power button down for 3-5 seconds and then release.



POWER OFF:

Press and hold the power button down for 3 to 5 seconds and then release.

Lithium Ion Battery

5

- Do not use or place the battery in direct sunlight and/or smokey, dusty environments.
- Do not strike, squeeze, and/or tread on battery.
- Do not throw the battery in any liquids or place in/near fires.
- If the battery is deformed or damaged, please stop using immediately and replace it.
- If the continuous working time is only half of a new battery, the battery life may be at its end. Please replace it.
- The specified battery model and charger must be used, otherwise there may be an explosion.



Note: Product images shown may be different than actual product received.

- The charging time cannot exceed 24 hours. If the battery is out of power, please recharge in an appropriate time and then disconnect the device. Avoid damaging the battery with over-charge and over-discharge.
- Please recharge the battery at least once every 6 months to avoid shortening its life.
- Replace battery every two years.
- Be sure to follow the instructions to dispose of wasted batteries.

Card Readers

6

- **Magnetic Stripe Card:** Slide the card through the card reader slot from left to right or from right to left with the magnetic strip oriented towards the body of the device. Make sure that the card is fully inserted into the card reader while swiping the card.
- **Smart Card Reader:** Insert the card fully into the reader with the metallic contacts facing up and towards the device. Make sure that the card is fully inserted into the card reader while scanning the card.
- **Contactless Card Reader:** The contactless card reader reads cards and devices placed roughly within an inch (2.5 mm). For best results, place as close to the reader as possible and center the card over the indicated area.

Environment

7

Working Environment	<ul style="list-style-type: none"> • Temperature: -10°C ~ 50°C (14°F ~ 122°F) • Humidity: 5% ~ 96% (without condensation)
---------------------	---



8

Cleaning the Device

- Do not use industrial strength or abrasive cleaner as it may damage or scratch the screen.
- Do not immerse the device in water or liquid.
- Do not spray water or cleaner into EMV Card Reader or ports.
- To clean the screen, apply distilled water or mild glass cleaner onto a soft, lint-free cloth and gently wipe terminal.

9

Installation and Usage Tips

1. If any cables become damaged, seek a replacement.
2. Do not insert unknown materials into any port on the A77; this may cause serious damage.
3. If repairs are required, please contact a professional technician instead of attempting them on your own.
4. Avoid exposing the device to an excessively hot, dusty, or strong electromagnetic environment.
5. Do not vibrate, shake, or drop the device.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the body of this equipment is a label that contains, among other information, a product identifier. If requested, this number must be provided to the telephone company.

RF Exposure Information

This device meets the government's requirement for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.


PAX Customer Support

For questions or help with the terminal installation please contact your service provider or PAX customer support.

Technical Support Contact Information:

Phone: (877) 859-0099
Email: support@pax.us
URL: www.pax.us

A77 Smart Mini POS Terminal



Note: Product images shown may be different than actual product received.

This document is provided to you for informational purposes only. All features and specifications are subject to change without notice. PAX's name and PAX's logo are registered trademarks of PAX Technology Inc. All Rights Reserved.



Responsible Party:
PAX Technology Inc.
8880 Freedom Crossing Trail,
Building 400, 3rd Floor, Suite 300
Jacksonville, FL 32256, USA
Help Desk: 877-859-0099
www.pax.us

PAX TECHNOLOGY INC.