Aries8 Pro Quick Setup Guide

CONTENTS CHECKLIST


Please check the box contents after unpacking. If any components are missing, or if there is a page missing from the quick setup guide, etc., please contact the dealer.


| Name | Qty. |
|-------------------------|------|
| Aries8 Pro Smart Tablet | 1 |
| Battery | 1 |
| Power Adapter | 1 |
| AC Cable | 1 |
| SIM Card Ejector Tool | 1 |
| Privacy Shield Set | 1 |

PRODUCT DESCRIPTION

The following section points out the various hardware features for the Aries8 Pro.

Front View





BASIC OPERATING INSTRUCTIONS

The following section provides basic operating instructions for the Aries8 Pro.

Power ON/OFF

- **Power ON:** Press and hold the power button on the right side of the terminal for 3-5 seconds.
- **Power OFF:** Press and hold the power button on the right side of the terminal for 3-5 seconds.

CARD READERS

The Aries8 Pro Smart Tablet includes the following card readers:

EMV Card Reader

Insert card with IC chip facing up, then push it to the end of the card slot with blue light flashing and icon displaying on screen. Leave card inserted until prompted to remove.

Magnetic Stripe Card


Insert magnetic stripe card into card slot and push to the end with magnetic stripe facing down, then pull out card at a constant speed to swipe card.

Contactless Card Reader

Hold contactless card over or under keypad to trigger payment.


SIM/SAM CARD AND BATTERY INSTALLATION

The Aries8 Pro includes slots for both SIM and SAM cards.




SIM/SAM Card

- 1. Use the SIM Card Ejector tool to open the tray.
- 2. Place the SIM card into the tray and then gently slide it back in place.




SAM Card

- 1. Open cover and insert card with chip facing up.
- 2. Replace cover.



Preparing Battery for Use


- 1. Open the battery cover on the bottom of the terminal.
- 2. Take out the battery.
- 3. Locate the white tab on the battery and peel back carefully until it is fully removed and the POGO pins are visible.



PRIVACY SHIELD INSTALLATION

The Aries8 Pro Kit includes two optional privacy shields: a high privacy shield and a low privacy shield.

- 1. Align four pegs on privacy shield with the four holes around the tablet keypad.
- 2. Press to secure privacy shield to keypad.



Please Note: Once installed, the high privacy shield cannot be removed without damaging the privacy shield or the tablet, while the low privacy shield can be removed without damage.

CLEANING THE DEVICE

- Do not use industrial strength or abrasive cleaner as it may damage or scratch the screen.
- Do not immerse the device in water or liquid.
- Do not spray water or cleaner into EMV Card Reader or ports.
- To clean the screen, apply distilled water or mild glass cleaner onto a soft,

lint-free cloth and gently wipe terminal.

TERMINAL INSTALLATION AND USAGE TIPS

- If any cables become damaged, seek a replacement.
- Before inserting card, please check the inside and periphery of the IC card slot.
- If there is any suspicious object, please report to the related administrator.
- Do not insert unknown materials into any port on the Aries8 Pro; this may cause serious damage.
- If repairs are required, please contact a professional technician instead of attempting them on your own.
- Avoid exposing the device to an excessively hot, dusty, or strong electromagnetic environment.
- Do not vibrate, shake, or drop the device.

For 5GHz WiFi version

FCC Compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which

the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC SAR statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body

ISED compliance statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

le dispositif utilisé dans la bande 5150-5250 MHz est réservé à une utilisation en intérieur afin de réduire le risque de brouillage préjudiciable aux systèmes mobiles par satellite dans le même canal;

IC SAR statement

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the ISED. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur.

Le dispositif portatif est conçu pour répondre aux exigences d'exposition aux ondes radio établie par le développement énergétique DURABLE. Ces exigences un SAR limite de 1,6 W/kg en moyenne pour un gramme de tissu. La valeur SAR la plus élevée signalée en vertu de cette norme lors de la certification de produit à utiliser lorsqu'il est correctement porté sur le corps.



Trademark notice:

"microSD logo is a trademark of SD-3C LLC."

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by PAX Technology, Inc. is under license. Other trademarks and trade names are those of their respective owners.

PAX Technology Inc reserves the right to change product technology specifications without notification.