

SK700 Quick Setup Guide

CONTENTS CHECKLIST


Please check the box contents after unpacking. If any components are missing, please contact the dealer.

Name	Qty.
SK700 Smart Kiosk	1
Wall Mount Bracket	1
VESA Bracket	1
M4-10 Combination Screw	2
Expansion Screw	6
Printer Key	2
Thermal Paper Roll	1
Power Cable	1
Plastic Packaging	1
Quick Setup Guide	1


PRODUCT DESCRIPTION

The following section points out the various hardware features and functions of the SK700.

Front View



Back View



INSTRUCTIONS

The following section provides basic operating instructions for the SK700.

Power ON/OFF

- **Power ON:** Plug in the AC power cable, press and hold the Power button for three seconds until the boot animation appears.
- **Power OFF:** Press and hold the Power button for three seconds until the shutdown menu displays. Select Power off. The terminal turns off after a few seconds.

Printer Paper Installation


The SK700 display will notify users when the device is out of printer paper. Complete the following to load a new thermal paper roll.

1. Insert the key into the keyhole and turn it counterclockwise to open printer cover.
2. Completely open the printer cover.
3. Insert the new paper roll into the printer.
4. Pull out the end of the paper so that it extends past the cutting blade.
5. Close the printer cover, and pull out the key. Printer will automatically cut off the extra paper, the paper is changed successfully.


WALL MOUNT BRACKET INSTALLATION

1. Use the six M6-50 expansion screws to attach the bracket onto the wall.

(**Note:** Use an 8.0 mm diameter drill bit to drill holes in the wall according to the position of the bracket fixing hole. Hole diameter is 8.0mm, Hole depth is above 60.0mm.)




2. Use the four hooks on the back of the device to hang the device on the wall mount bracket. The hole diameter is 8mm.




3. Use the two M4-10 combination screws to attach the device to the wall mount bracket at the bottom of the device.
4. If you have a custom PAX-designed metal stand, you can attach the machine directly to the stand.

VESA BRACKET INSTALLATION (OPTIONAL ACCESSORY)


1. Remove the mounting pieces from the back of the SK700.



2. Use the screws from Step 1 to mount the VESA bracket adapter to the back of the SK700.



3. Use the 4 M6 screws to mount the PAX VESA bracket adapter to the VESA bracket.
4. Our VESA bracket adapter has the following sets of holes pre-drilled to match the VESA scale.



CARD READERS

The SK700 includes the following card readers:

NFC/Contactless Card Reader

The contactless card reader reads cards and devices placed roughly within an inch (2.5 mm). For best results, place the card as close to the reader as possible and center the card over the indicated area on the terminal.

Magnetic Stripe Reader

Insert magnetic stripe card into card slot and push to the end with magnetic

stripe facing down, then pull out the card at a constant speed to swipe card.

EMV/Smart Card Reader

Insert card with IC chip facing up, then push it to the end of the card slot. Leave card inserted until prompted to remove.

CLEANING THE DEVICE

- Do not use industrial strength or abrasive cleaner as it may damage or scratch the screen.
 - Do not immerse the device in water or liquid.
 - Do not spray water or cleaner into ports.
 - To clean the screen, apply distilled water or mild glass cleaner onto a soft, lint-free cloth and gently wipe terminal.
-

TERMINAL USAGE TIPS

- If any cables become damaged, seek a replacement.
- If there is any suspicious object, please report to the related administrator.
- Do not insert unknown materials into any port on the SK700; this may cause serious damage.
- If repairs are required, please contact a professional technician instead of attempting them on your own.
- Avoid exposing the device to an excessively hot, dusty, or strong electromagnetic environment.
- Do not vibrate, shake, or drop the device.
- There is no built-in battery. The device can only be powered using the power adapter.

For 5GHz WiFi version FCC compliance statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: – Reorient or relocate the receiving antenna. – Increase the separation between the equipment and receiver. – Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. – Consult the dealer or an experienced radio/TV technician for help. **FCC SAR statement** This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body **ISED compliance statement** This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems; le dispositif utilisé dans la bande 5150-5250 MHz est réservé à une utilisation en intérieur afin de réduire le risque de brouillage préjudiciable aux systèmes mobiles par satellite dans le même canal; **IC SAR statement** This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the ISED. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body. Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Le dispositif portatif est conçu pour répondre aux exigences d'exposition aux ondes radio établie par le développement énergétique DURABLE. Ces exigences un SAR limite de 1,6 W/kg en moyenne pour un gramme de tissu. La valeur SAR la plus élevée signalée en vertu de cette norme lors de la certification de produit à utiliser lorsqu'il est correctement porté sur

le corps.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by PAX Technology, Inc. is under license. Other trademarks and trade names are those of their respective owners.

PAX Technology Inc reserves the right to change product technology specifications without notification.